

G120 TRACKER FITTING GUIDE

Fitting time approx. 30mins



Tools required

- Zip Ties
- Cutters
- Wire connection tools



Step – 1 Preparation

- Please note this tracker is not waterproof
- Identify the location of where you will fit the tracker
- The tracker should be located away from areas where it can become damaged.
- It should have no metal obstruction between the box and the sky for best results.
- It should not be in direct vision of people entering the vehicle.
- The tracker should not impede the operation of the vehicle and all cables must be out of the way of the driver/operator.





Wiring Diagram

Black (pin 12)= Chassis Ground

Red (pin 24)= Permanent Power

White (pin 23)= Connected to alternator signal wire or Ignition position "Engine On" (indicates engine is running).

Pink (pin 16)= Input 1

Step 2 - Location

- Remove steering column cover
 - Identify permanent power, earth and ignition power on ignition barrel, alternatively the fuse compartment may contain the required inputs.
- Place LMU the correct way up under the dash.
 - Ensure TFO sticker faces down
 - Ensure unit is secured (must not move)
 - Ensure unit is away from source of heat/moisture
- Pack away
 - Replace covers.



Step 3 - Fitting

Connect wires

RED = Permanent power (Must be fitted with Max 5A fuse in line)

Black = Earth

White = Ignition ON power (Not ACC) (Must be fitted with

Max 5A fuse in line)

Pink = Input 1. This can be used to monitor Seatbelt connection,

PTO engagement or some other type of trigger

If no extra monitoring is required leave Pink wire Free.



Scan for Install Troubleshooting

Step 4 – Activation

- Start the asset and let it run for 5 minutes.
- Turn asset off and scan the QR code with your phone. Allow location services.
- Follow the steps through the activation app.
- You will need details about the asset and the tracker number to complete the activation
- Please call 1300 110 248 If you have any issues with the activation for assistance



Scan for Activation App